

# NEC

## ELITE IPK/48/192 WITH NO VOICEMAIL

### ADMINISTRATION GUIDE



# Table of Contents

**Phone Outline..... 3**

**Phone System Programming..... 4**

Changing the Time: ..... 4

Changing the Date: ..... 4

Program Call Forward Busy/No Answer to Voicemail: ..... 4

Programming System Speed Dials:..... 4

**\*\* Important Note:**

The extension and mailbox numbers referenced in this guide are the most commonly used configuration. It does **not** guarantee that your company will use the same extension and mailbox numbers due to each systems **customized** configuration. If you are **unsure** of what numbers were used in your configuration, please call or email the NATG service department.



## Phone Outline



<b>ONE TOUCH KEYS</b> .....	Used for features, line keys, intercoms and speed dials
<b>EXIT</b> .....	Exit's out of various programming
<b>SOFT KEYS</b> .....	Corresponds with what the display says
<b>MESSAGE INDICATOR</b> .....	Flashes when you have a voicemail
<b>HELP</b> .....	Tells how a one touch key is programmed
<b>RECALL</b> .....	Same as Flash Key for various features
<b>FEATURE</b> .....	Used for programming
<b>DIRECTORY</b> .....	Access to station and system wide speed dials
<b>MESSAGE</b> .....	Access to your voicemail
<b>MIC</b> .....	Mutes the microphone while on speakerphone
<b>CONF</b> .....	Used to make conference calls
<b>REDIAL</b> .....	Review the last numbers dialed
<b>DOWN/UP</b> .....	Adjusts the volume on the ringer, handset and speaker
<b>ANSWER</b> .....	Answers the FIRST incoming call to a specific phone
<b>SPEAKER</b> .....	Speakerphone (Also used to get in/out of some programming)
<b>TRANSFER</b> .....	Transfer a call to another extension
<b>HOLD</b> .....	Holds the call



## Phone System Programming

### Changing the Time:

1. Press the **Feature** Key
2. Dial **9#**
3. Enter the **hour** and the **minute** via the dial pad
4. Press the **RECALL** Key to change the **AM/PM** setting
5. Press the **FEATURE** Key to exit this feature

### Changing the Date:

1. Press the **Feature** Key
2. Dial **9#**
3. Press the **RECALL** Key
4. Press the **RECALL** Key again
5. Dial **#** to move the cursor to the **day of the month field**
6. Enter the **day of the month** via the dial pad
7. Press the **RECALL** Key to select the month
8. Dial **#** to move the cursor to the year field
9. Enter the **last two digits** of the **year** via the dial pad
10. Press the **Feature** Key

**Note:** The above changes the time on the *Phone System only*. If you have voicemail, you will have to change the time in that as well.

### Program Call Forward Busy/No Answer to Voicemail:

\* \* Must be done from the extension you would like to call forward

1. Press **Speaker**
2. Enter **43**
3. Enter Voicemail Extension Number (Usually it is 300)
4. Press **Speaker**

### Programming System Speed Dials:

\* \* Must be done from the System Admin Phone (usually 100)

1. Press **Feature** key
2. Press **Redial** key
3. Enter the **speed dial number** you'd like to program (goes from SPD 00 to 79)
4. Enter **9 + the phone number** (enter a 1 in front for long distance)
5. Press **Hold** key
6. **Spell Name**, press **#** after each letter to move the cursor to the **right** or **Conf** key to move the cursor to the **left**
7. Press **Speaker**

