

# **PHONE OUTLINE:**



- Message Indicator Indicates message waiting
- Line Keys Used to show active calls and feature keys
- Softkeys Accesses the feature/function that appears on the display above them. Softkeys change
- Navigation Keys Scroll through information or options displayed on the screen. + Access History and Directory
- Mute Key Toggles the microphone on/off
- Headset Key Toggles the headset mode on/off
- Message Key Accesses voicemail
- Redial Key Redials a previously dialed number
- **Speakerphone** Toggles and indicates the hands-free mode.
- Volume Key Adjusts the volume of handset, headset or speaker
- X = Cancel Key Cancels actions, exits menus or rejects incoming calls
- OK Key Confirms actions or answers incoming calls

For Online Video on step-by-step features click here: https://vimeo.com/697489726



## PHONE INSTRUCTIONS

#### DIAL OUT:

- Lift **Handset** or press **Speaker** Key
- Dial Number
- Press the **Send** softkey (on the display)

### **MUTE:**

To Mute yourself (You can still hear caller), press the **Mute** button



To Un-Mute yourself, press the illuminated **Mute** button



#### ANSWERING A CALL:

- Pick up **Handset**
- Press the **Speaker** key or
- Press the **Answer** softkey (on the display). This will answer on speakerphone

### TRANSFER A CALL:

Warm/Attended Transfer (Allows you to introduce the call to the recipient before completing the transfer)

- While on an active call, press the **Trans** softkey (on the display)
- **Dial** the **number** you want to transfer the call to (internal or external)
- Announce call
- Press the Trans key again. Then Hang up

Blind Transfer (Transfers the call directly without prior notification to the recipient)

- While on an active call, press the **Trans** softkey (on the display)
- **Dial** the **number** you want to transfer the call to (internal or external)
- Press the B Trans key, then hang up

To cancel: Press the Cancel softkey

To Transfer Directly to Voicemail: Press Trans, press \*, followed by the extension, then hang up

## PERSONAL HOLD:

Holds call on your handset only

With an active call, press the **Hold** softkey (on display)

To retrieve call: lift handset, press your flashing like key or press the Resume softkey

### **PARK HOLD:**

Holds call system wide

With an active call: press Park key; System will automatically designate the park number for you

To Retrieve Call: lift handset and dial Park number or press the Park button (if applicable)

#### **REDIAL:**

With the handset in the cradle...

- Press **Redial** key
- Press Up and Down arrows to review last 20 numbers you have called
- Pick up handset to dial number on display



### **CALLER ID:**

- Press the **History** softkey (on display)
- The LCD screen displays all records
- Use < or > to switch among All Calls, Missed Calls, Placed Calls, Received Calls and Forwarded Calls
- Use < or > to scroll through calls
- On the selected number, you can press the Option softkey, and then select detail to view more information about the call or
- Press the **Send** softkey to call number

#### **CONFERENCE CALL:**

- Start a regular call with one of your contacts or any external number
- Press the Conference softkey (on display)
- Call the next person you would like to conference in
- Once call is connected, press the Conference softkey again

To End Conference: Hang up

### DND:

Press the DND key to activate DND. When active you will have a DND symbol on your display
To Deactivate: Press the DND key again

## **CALL FORWARDING:**

To turn Call Forwarding on:

- 1. Press the **Menu** softkey (on display)
- 2. Navigate to Features, press OK
- 3. Navigate to Call Forward, press OK
- 4. With Always Forward highlighted, press OK
- 5. See Always forward: Off, scroll > to toggle On
- 6. Scroll Down to forward to and Enter the number you want to transfer the call to
- 7. Press Save.

### To turn Call Forwarding Off:

- Follow steps 1 4, and toggle to Off
- Press Save.

## **ADJUSTING RING & SPEAKER VOLUME:**

To adjust Ring Volume:

- With the handset in the cradle, press the Volume button **Up** and **Down (Example 2)** to adjust the volume *To adjust Handset & Speaker Volume:*
- While on and active call, press the Volume button Up and Down I to adjust the volume.



## **VOICEMAIL**

#### **ACCESSING YOUR MAILBOX:**

- Press your Message key
- Enter default PIN [provided by NATG], then press #

#### **CHANGING YOUR PIN:**

- Press your Message key
- Enter default PIN, then press #
- Press 3 for Personal Options
- To change your PIN, press 2
- Enter a 4 10 digit PIN, then press the # key when done
- Press \* to return to the main menu

### **RECORDING YOUR GREETING:**

- Press your Message key
- Enter your PIN, then press #
- Press 3 for Personal Options
- Press 1 to Record your voicemail
- After listening to your current greeting, press 1 to record a new greeting
- Record your greeting, press # when finished
- After reviewing your greeting, press 1 to accept it

#### LISTENING TO MESSAGES:

- Press your Message key
- Enter your PIN, then press #
- Press 1 to listen to New messages
- Press 2 to listen to Old message
- While listening to the message, press:
  - 1 replay the current message
  - o 2 delete the VM
  - 5 confirm the deletion
  - 3 mark message as unheard
  - 4 skip the current message
  - 5 callback the sender of the voicemail
  - 6 forward voicemail to the extension
  - # skip the playback of message details

## **CHECKING YOUR VOICEMAIL REMOTELY:**

- From an outside line call your direct number
- When the voicemail greeting begins, press #
- Follow the voice prompts please enter your extension, Press # when done
- Follow the voice prompts please enter your PIN code. Press # when done
- Follow the voice prompts and select your desired task:
  - Press 1 to listen to new voice messages
  - Press 2 to listen to old messages.
  - Press 3 for personal options this also allows you to update your voicemail greeting

