





## **DIGITAL HANDSET 7449 QUICK REFERENCE**

### **To DIAL OUT:**

- Press , dial 9 followed by phone number
- Press  to end call

### **To LOCK/UNLOCK THE HANDSET:**

- Press  (Menu) followed by \*

### **INTERCOM CALLS:**

- Press , dial extension

### **ANSWER OR DISCONNECT A CALL:**

- Press 

### **ANSWER A SECOND CALL WHILE ON ANOTHER CALL:**

- Press **R** (Automatically will put the first caller on hold)
- Press **R** again to return to the first call


### **To PLACE A CALL ON HOLD:**

- While on a call, Press **R**

#### **To Retrieve the held call:**

- Press **R**

### **REDIAL:**

- Press /C
- Press < or > to scroll through
- Press **R** to Release

### **To SILENT THE DIGITAL HANDSET:**

- Press  (Menu) followed by #



### **To ADJUST RINGER VOLUME:**

- Press ≡ (Menu)
- See “Profile Set Up” Press √
- Press > until you see “Ringer Vol”
- Press √
- Use < or > to turn the volume up or down
- Press √ to confirm

### **SELECT RING TONE:**

- Press ≡ (Menu)
- See “Profile Set Up” Press √
- See “Ringer Tone” Press √
- Press < or > to scroll Through
- Press √ to select ring tone
- Press R to Release

### **To ADJUST KEY TONE:**

- Press ≡ (Menu)
- See “Profile Set Up” Press √
- Press > until you see “Key Click”
- Press < or > to adjust key click volume
- Press R to Release

### **To TURN VIBRATE ON/OFF:**

- Press ≡ (Menu)
- See “Profile Set Up” √
- Press > until you see “Vibrator”
- Press √
- Press > to change from on to off
- Press √ to confirm
- Press R to Release

